

FS-250 OPERATING INSTRUCTIONS

Alarm Operation

In case of alarm, the *Alarm* LED flashes, LCD displays alarm condition and the panel buzzer sounds steady. Local audible and visual signals and remote alarm signals operate.

When an alarm occurs, proceed according to the established emergency plan. Assure that all personnel are accounted for, and notify the Fire Department to advise of the alarm and/or verify that an automatic signal has been received at the Fire Department.

Authorized Personnel Only

To acknowledge the alarm:

To acknowledge the alarm, press the *Acknowledge* button. The local buzzer will be silenced and the *Alarm* LED will change from on-flashing to on-steady.

To silence the alarm:

To silence the notification appliances after evacuation, where permitted, press the *Alarm Silenced* button. The silenceable notification appliances will be silenced. The *Alarm Silenced* LED will be on-steady.

Note: Do not reset the panel until the alarm has been cleared.

Warning: Alarm silence inhibit (if set) prevents the alarm from being silenced for a predetermined time.

To reset panel after alarm:

When the alarm condition is corrected, return the panel to normal standby operation by pressing the *System Reset* switch.

Trouble Operation

Trouble is indicated by:

Trouble LED flashes
LCD will display trouble conditions
Panel buzzer sounds on-pulsing

To acknowledge the trouble buzzer:

Press the *Acknowledge* button. The *Trouble* LED turns on-steady and the buzzer turns off. When the trouble condition has been cleared, you may need to reset the panel to restore to a normal standby condition.

Warning: Leaving the panel in a trouble condition may cause a fire alarm condition not to initiate a fire alarm sequence.

Normal Standby Condition

The green *AC Power On* LED will be lit and no other indicators on.

For service, contact: _____
Telephone Number: _____

Frame these instructions and mount them near the control panel for operator reference.